

Instruction Manual

Cyclone Catcher with Sludge Tank

C-Jaguar



Warning

- ◆ This apparatus is designed to filter a water-soluble grinding fluid, a wire-cut EDM (electric discharge machining) fluid, etc. Do not use this apparatus for any other purpose.
- ◆ Read this Instruction Manual carefully and understand the descriptions before operating this apparatus or performing maintenance/inspection work.
- ◆ Store this Instruction Manual carefully so that you can review it whenever operating this apparatus or performing maintenance/inspection work.

Contents

| | |
|--|----|
| 1. Safety Precautions | 1 |
| 2. Introduction | 2 |
| 3. Unpacking Check | 2 |
| 4. Installation | 2 |
| 5. Operation | 4 |
| 6. Maintenance and Inspection | 5 |
| 7. Troubleshooting | 7 |
| 8. Replacement of ADAPTER | 8 |
| 9. Replacement of Ball valve with actuator (SV2) | 10 |
| 10. Repair and Warranty | 12 |

Attachments



Outline Drawing, Flow Chart, Control Panel
Outline Drawing, Electrical Diagram, Timing
Diagram, VDF Instruction Manual, Pump
Instruction Manual

Nikuni Co., Ltd.



843-5 Kuji, Takatsu-ku, Kawasaki City, Kanagawa JAPAN 213-0032
TEL: +81-44-833-1121 (Main Switchboard)

1. Safety Precautions

In this Instruction Manual, safety precautions are divided into “Warning” and “Caution” according to level to allow you to use the product safely and properly and prevent harm and damage to the user and others in the area.

| | |
|--|---|
|  Warning | Failure to observe the indicated warning could result in death or serious injury of the user or others in the area. Understand the descriptions fully and follow the instructions without fail. |
|  Caution | Failure to observe the indicated caution could result in impairment of the user or others in the area or property damage. Understand the descriptions fully and follow the instructions without fail. |

The following symbols are also used with those shown above to allow for normal operation and prevent a reduction in the product life and failures. Be sure to follow the instructions.

| | |
|---|--------------------------------------|
|  Prohibited | Indicates what you must not do. |
|  Forced | Indicates what you are forced to do. |



Warning

- ◆ Carry out wiring work properly according to the Technical Standards on Electrical Equipment and Indoor Wiring Regulations. Incorrect wiring work may result in electric shocks or fire.
- ◆ Before maintenance, inspection or part replacement, turn off the source power. Failure to do so may result in electric shocks, or personal injury due to accidental starting of the machine.
- ◆ Establish a ground securely. Failure to do so may result in electric shocks during a machine failure or short-circuit.
- ◆ Do not open the switch box or the motor terminal box unnecessarily. Doing so may result in electric shocks.
- ◆ Do not splash water on live parts. Doing so may result in a short circuit, electric shocks or a machine failure.



Caution

- ◆ This apparatus is designed to filter a water-soluble grinding fluid, a wire-cut EDM fluid, etc. Do not use this apparatus for any other purpose.
- ◆ Do not move or carry piping or equipment by hand. Doing so may result not only in property damage but also in personal injury.
- ◆ Do not touch the motor or pump during or immediately after operation. Doing so may result in burns due to high temperature.
- ◆ Do not cover the motor with a blanket or cloth. Doing so may result in ignition by overheating.

2. Introduction

- 2-1. This apparatus is a unit that uses VDF(Vortex Dynamic Filter) compatible with a water-soluble grinding fluid and a wire-cut EDM fluid. Consult us when using any fluid other than the above.
- 2-2. When any work material with a specific gravity of 2.5 or less is used, filtration efficiency decreases due to the property of VDF. Consult us when using any work material with a lower specific gravity.
- 2-3. Use the apparatus while the height from the coolant tank fluid level to the pump inlet port is within one meter.



Caution

- ◆ This apparatus is designed to filter a water-soluble grinding fluid, a wire-cut EDM fluid, etc. Do not use this apparatus for any other purpose. Doing so may result in unexpected accidents or personal injury.

3. Unpacking Check

After receiving the apparatus, check the following:

1. Check that the product is as per order with the Delivery Specification.
2. Check that the product is not damaged and the bolts/nuts have not come loose during transport.
3. Check that accessories are all supplied.
4. In the case of any defective condition, contact your dealer by specifying the product model and serial number described on the nameplate.

4. Installation

4-1.Apparatus movement and carriage

When moving or carrying the apparatus, lift the stand with a forklift etc.

The apparatus is unstable since its center of gravity is high. Therefore, move or carry the apparatus carefully to prevent it from falling down.



Caution

- ◆ Do not move or carry the apparatus in an unstable condition. Doing so may result not only in apparatus damage but also in personal injury.

4-2.Installation




- 1) This apparatus is designed for inside installation. Install it above the working fluid tank or on the periphery of the tank of a machine tool.
- 2) Avoid the suction piping of the apparatus from sucking in fluid from sludge accumulated places, extremely contaminated tanks or places where sludge of more than 150μm is mixed.
- 3) Secure maintenance space as well as space for piping and wiring connections around this apparatus.



Avoid the suction piping of the apparatus from sucking in fluid from sludge accumulated places, extremely contaminated tanks or places where sludge of more than 150μm is mixed.

4-3.Piping

- 1) Suction piping
 - a) Connect a hose which matches a suction opening. Refer to the outline drawing of the appendix for the hose size.
 - b) Use a suction hose.
 - c) Install piping in such a way as to avoid air suction and dead air space.
 - d) Avoid the suction piping from sucking in fluid from sludge accumulated places, extremely contaminated tanks or places where sludge of more than 150 μ m is mixed.
 - e) Install piping appropriate to the fluid temperature and fluid quality used.
 - f) Never close the gate valve at the suction port.

-  Use a suction hose.
-  Prevent chips from mixing into the unit.
-  Never close the gate valve at the suction port.

- 2) Clean fluid return piping
 - a) Return a hose from the nipple for a hose measuring 32 mm in internal diameter to the working fluid tank and fix it in a submerged state.
 - b) Install piping appropriate to the fluid temperature and fluid quality used.

4-4.Electric wiring

- 1) Carry out wiring work properly according to the Technical Standards on Electrical Equipment and Indoor Wiring Regulations. Improper wiring work or grounding by unqualified personnel is not only illegal but also very dangerous. Never perform such work.
- 2) Be sure to install an earth leakage breaker on the source power to prevent electric shock accidents.
- 3) Match the apparatus source voltage with the power supply voltage.
- 4) Use an electric wire with a cross-sectional area of 2 mm² or more for the power source.

4-5.Compressed air supply

- 1) Supply compressed air within the 0.4 MPa to 1.0 MPa range.
Using air outside this range causes a failure or malfunction.





**Warning**

- ◆ Carry out wiring work properly according to the Technical Standards on Electrical Equipment and Indoor Wiring Regulations. Incorrect wiring work may result in electric shocks or fire.
- ◆ Before maintenance, inspection or part replacement, turn off the source power. Failure to do so may result in electric shocks, or personal injury due to accidental starting of the machine.
- ◆ Establish a ground securely. Failure to do so may result in electric shocks during a machine failure or short-circuit.
- ◆ Do not open the switch box or the motor terminal box unnecessarily. Doing so may result in electric shocks.
- ◆ Do not splash water on live parts. Doing so may result in a short circuit, electric shocks or a machine failure.

5. Operation




5-1. Operation preparation

- 1) Recheck that installation, wiring and piping are properly executed.
- 2) Feed fresh water or the working fluid used to the "UPPER LEVEL" of the FLOAT SWITCH.
- 3) Turn the shaft lightly with a flat-blade screwdriver from the rear of the cyclone pump motor to check that movement is not slow or nonuniform.
- 4) Prime the pump from the priming cup. After removing the plug from the priming cup, prime the pump with fresh water or the working fluid used until the pump is filled to capacity and tighten the plug.
- 5) Set the change-over switch CONVEVER (COS2) to AUTO.
- 6) Turn on COS1 and turn on/off the earth leakage breaker (ELB) to visually check from the rear of the cyclone pump motor that the pump rotation direction (clockwise rotation) is proper when seen from the motor side. After checking it, turn off the ELB.
- 7) Before reversing the rotation direction, turn off the power temporarily and interchange 2 out of 3 electric wires. Check the rotation direction by inching.
- 8) Turn on the ELB and turn on COS1.
- 9) Check that the fluid starts to flow from the clean fluid return piping and the pressure gauge indicates 0.15 MPa or more. After operation start, open SV2 to start fluid supply to the sludge tank. When the fluid level reaches the upper limit, close SV2 and open SV3.
- 10) Check that there is no fluid leak from the piping and the sludge tank.
- 11) Turn off the ELB to stop it.
Stopping COS1 enters a cycle stop and the pump stops after completion of one cycle.

-  Do not run the pump at idle (dry operation), since doing so causes a failure.
-  Do not run the pump by reversing the rotation direction, since doing so causes a failure.
-  Prime the pump with reliability. Insufficient priming may not pump fluid up.
-  After inspecting or cleaning the pump, tank, etc., be sure to prime the pump.

5-2.Operation

- 1) Recheck that installation, piping and wiring are properly executed.
- 2) Turn on the ELB. The power lamp (WL1) lights up.
- 3) In the case of COS1 operation or external operation signal ON, turn on IN1 and 0V.
With the pump starting, operation starts.
- 4) Repeated automatic operation is performed by taking the pump operation filtration start, tank supernatant discharge and sludge pot concentrate discharge as one cycle. Refer to the Timing Diagram to check operation.
- 5) The setting of the precipitation time timer can be changed with T1 in the operation panel. (Initial set value: 30 min.)
If the sludge concentration in dirty fluid is high, the cyclone body or piping may be clogged with significantly accumulated sludge in a sludge pot. In that case, set the precipitation time timer (T1) for a shorter time.
- 6) Stopping COS1 or turning off the external operation signal makes pump operation (GL1) flash and enters a cycle stop. The pump stops and GL1 goes out after completion of one cycle. Turn off the power after a cycle stop has been completed. Turning off the power during a cycle stop causes piping clogging or a failure due to disabled sludge pot concentrate discharge.

-  Do not run the pump at idle (dry operation), since doing so causes a failure.
-  Do not run the pump by reversing the rotation direction, since doing so causes a failure.
-  Turn off the power after a cycle stop has been completed.
Failure to do so may cause sludge pot clogging due to disabled sludge pot concentrate discharge.

6. Maintenance

6-1.Maintenance

Inspect this apparatus periodically to prevent troubles from occurring under the influence of the operating environment such as the temperature, humidity and dust or due to secular change or life of the part used.

Periodic Inspection Table

| Inspection Item | Evaluation Standard | Frequency |
|--------------------------------------|--|----------------------|
| Supply pressure low | 0.15 MPa or more | Within every 1 month |
| Water leak from pump mechanical seal | Leak rate: 10 cc/hr. or less | Within every 1 month |
| Motor bearing temperature | Room temperature: +40°C or 75°C or less | Within every 1 month |
| Wiring damage | No damage | Within every 1 month |
| Current value | Not to exceed rated current | Within every 1 month |
| Earth leakage breaker operation | Normal operation | Within every 1 month |
| Thermal relay operation | Normal operation | Within every 1 month |
| Indicator lamp indication | Normal indication | Within every 1 month |
| Pressure switch set value | According to set value in attached table | Within every 1 month |
| Timer set value | According to set value in attached table | Within every 1 month |
| Air regulator setting | According to set value in attached table | Within every 1 month |
| Tightening of each bolt | Tightened securely | Within every 1 month |
| ADAPTER | Not worn out | Within every 1 month |
| S V 2 | Not worn out | Within every 1 month |

List of Set Values

| Symbol | Name | Application | Installation Place | Initial Setting | Current Setting |
|--------|-----------------|------------------------------|--------------------|-----------------|-----------------|
| T1 | Timer | Precipitating time setting | In operation panel | 30 min | min |
| PS | Pressure switch | Air pressure error detection | Tank body | 0.3 MPa | MPa |
| — | Air regulator | Air pressure adjustment | Tank body | 0.4 MPa | MPa |

Each setting of the timer (T1) can be changed. When changing its setting, consider the following tendencies:

- When a longer T1 time is set, a longer precipitation time is taken and the concentration amount in a sludge pot becomes larger.
- When a shorter T1 time is set, a shorter precipitation time is taken and the concentration amount in a sludge pot becomes smaller.

Please take note that setting a longer T1 time to make the concentration amount in a sludge pot larger may clog piping or the sludge pot.

If you have any questions about the setting, contact us.

**Warning**

- ◆ Before performing an overhaul, turn off the source power and check that electric current is not passed. Failure to do so may result in personal injury due to accidental starting of the machine.
- ◆ Before performing control panel maintenance/inspection or part replacement, turn off the source power and check that electric current is not passed. Failure to do so may result in electric shocks.

6-2. Notes when stopping for a long term

- 1) The pump and piping might be damaged by freezing the liquid for a short stop period to say nothing of time when driving is stopped for a long term in winter etc.
Please put out the liquids that exist in the tank and piping. Or, please warm the liquid.
- 2) Please do not generate rust at finished surface in the bearing etc.
Please turn the axis edge of the pump motor once a month.
- 3) Please put out the liquids when you use the liquid that the conveyer might rust.

7. Troubleshooting

When an error occurs, indicator lamps on the operation panel surface (RL1 to RL4) light up. In the case of an error occurrence, find out the cause and take measures against it immediately.

To restart the apparatus, remove the cause and press the reset button (PBS2). If the error does not fall under any in the table below or a part is damaged, contact your dealer or us.

| Indicator Lamp Name | Probable Cause | Remedy |
|-----------------------------|--|--|
| Overload (RL1) | <ul style="list-style-type: none"> - Piping or VDF clogging - Malfunction of actuator valve - Overload operation of motor - Foreign matter caught in pump - Too large specific gravity or viscosity of fluid - Open-phase operation - Voltage reduction | <ul style="list-style-type: none"> - Clean it. - Replace the part. - Request the manufacturer to repair it. - Request the manufacturer to repair it. - Review the plan. - Repair or replace equipment. - Check the voltage. |
| Full capacity (RL2) | <ul style="list-style-type: none"> - Apparatus filled to capacity with cleaning fluid - Contamination of FLOAT SWITCH - FLOAT SWITCH breakdown | <ul style="list-style-type: none"> - Drain the cleaning fluid. - Clean the part. - Replace the part. |
| Fluid discharge error (RL3) | <ul style="list-style-type: none"> - Clogging of piping - Malfunction of actuator valve - Contamination of FLOAT SWITCH - FLOAT SWITCH breakdown | <ul style="list-style-type: none"> - Clean it. - Replace the part. - Clean the part. - Replace the part. |
| Air pressure low (RL4) | <ul style="list-style-type: none"> - Insufficient source pressure - Pressure switch (PS) setting failure or breakdown - Air regulator setting failure or breakdown | <ul style="list-style-type: none"> - Check the source pressure. - Readjust or replace it. - Readjust or replace it. |
| Pressure value | <ul style="list-style-type: none"> - Suction piping clogging - Worn impeller out - Please refer to the pump instruction manual. | <ul style="list-style-type: none"> - Clean it. - Replace the part. |

There is no influence in the sludge elimination factor even if the pressure gauge display becomes 0.15MPa or less. However, please take note that clean flowing quantity decreases.



Warning

- ◆ Before performing an overhaul, turn off the source power and check that electric current is not passed. Failure to do so may result in personal injury due to accidental starting of the machine.
- ◆ Before performing control panel maintenance/inspection or part replacement, turn off the source power and check that electric current is not passed. Failure to do so may result in electric shocks.

8. The exchange method of ADAPTER

ADAPTER in the union which has piped VDF is worn out according to an operating condition. The protection effect over Ball valve with actuator (SV2) may be lost. It exchanges, when having worn ADAPTER out in the case of a scheduled inspection.

The order of “ADAPTER” is asked to our company.

The following tools are prepared for clearing work.

- Pipe wrench (range of use : 10 ~54mm)
- Motor wrench
- Adjustable wrench

In the case of clearing work, shut off the power of supply. Working gloves are worn so that it may not be injured.



8-1. Exchange method

- 1) Drain the liquid in the main part of the sludge tank from the drain beforehand.
Stop compressed air supply and check in meter that the air in a unit has fallen out completely. Turn the shaft in the actuator portion of SV2, open a valve, and drain the liquid in a VDF and a Sludge-pot.
- 2) A union is removed and ADAPTER is taken out.
- 3) A union is fastened after putting new ADAPTER into a union.
- 4) Connect an air tube as the following "electromagnetic valve - actuator connection table".
- 5) Supply compressed air, check whether supply pressure is 0.4 MPa, and switch on a power supply.
- 6) Resume operation and check that there is no liquid leak from piping.



Warning

- ◆ Put packing into a union and pipe it certainly.
Otherwise, a possibility of causing a liquid leak is during operation.



Electromagnetic valve - actuator connection

| | | Electromagnetic valve | | |
|------|---|-----------------------|-----|-----|
| | | SV1 | SV2 | SV3 |
| Port | A | O | O | O |
| | B | S | S | S |

9. Replacement of Ball valve with actuator (SV2)

Ball valve with actuator (SV2) is worn out according to an operating condition, and a liquid leak arises. Then RL2 (OVER FULL) blinks. Then “SV2” is exchanged.

When there are many amounts of liquid leaks, RL2 is changed to lighting from blink and becomes a “Full-of-water alarm”.

The order of “SV2” is asked to our company.

The following tools are prepared for clearing work.

- Pipe wrench (range of use : 10 ~54mm)
- Motor wrench
- Adjustable wrench

In the case of clearing work, shut off the power of supply. Working gloves are worn so that it may not be injured.


9-1. Exchange method

- 1) Drain the liquid in the main part of the sludge tank from the drain beforehand.
Stop compressed air supply and check in meter that the air in a unit has fallen out completely. Turn the shaft in the actuator portion of SV2, open a valve, and drain the liquid in a VDF and a sludge-pot.
- 2) Draw out the air tube linked to an actuator.
- 3) Remove SV2 and a long nipple after removing a union. Remove the sludge which has collected in the sludge-pot or the long nipple.
- 4) Attach a long nipple and new SV2 and connect a union. At this time, be sure to rewind a tape seal, pipe certainly. Put packing into a union and pipe it certainly.
- 5) Connect an air tube as the following "electromagnetic valve - actuator connection table".
- 6) Supply compressed air, check whether supply pressure is 0.4 MPa, and switch on a power supply.
- 7) Resume operation and check that there is no liquid leak from piping.



Warning

- ◆ Be sure to roll a tape seal and to pipe certainly, when you pipe.
Put packing into a union and pipe it certainly.
Otherwise, a possibility of causing a liquid leak is during operation.



Electromagnetic valve - actuator connection

| | | Electromagnetic valve | | |
|------|---|-----------------------|-----|-----|
| | | SV1 | SV2 | SV3 |
| Port | A | O | O | O |
| | B | S | S | S |

10. Repair and Warranty

For repair and maintenance of your purchased product, contact your dealer or us. We shall repair the product at no charge under the conditions shown below. However, the warranty of this product is limited to use within Japan.

1. The warranty term of this product shall be one year after the final acceptance.
2. Where the product becomes faulty or damaged due to a defect in our workmanship in spite of your normal use during the warranty term, we shall repair the faulty/damaged part of this product at no charge. In this case, we shall bear the expenses for repair parts and engineer dispatching but be exempted from other expenses.
3. However, the following failures/damages and consumables will be repaired or replaced at charge:
 - 1) Failures/damages occurring after the termination of the warranty term
 - 2) Failures/damages resulting from abnormal use or storage
 - 3) Failures/damages resulting from disasters or force majeure such as fire, natural disasters and acts of God
 - 4) Failures/damages occurring where a part is replaced by the user
 - 5) Failures/damages resulting from repair or modification by the user



* Consumables are parts for which wear and tear is expected from the beginning, such as packing, O-rings, mechanical seals and bearings.
4. We shall not compensate for various expenditures and other damages resulting from failures occurring during the use of this product. When any abnormal condition is detected during the use of this product, inspect it by referring to "7. Troubleshooting" to determine whether the product is faulty or not. In the case of a failure, contact us immediately. At that time, inform us of the product model and serial number described on the nameplate as well as the failure (error) conditions.

If you have any questions or comments about your purchased product, feel free to contact us.


For inquiries:

Nikuni Co., Ltd.

| | |
|-----------------------|---|
| Head Office: | 843-5 Kuji, Takatsu-ku, Kawasaki City, Kanagawa JAPAN 213-0032 TEL: +81-44-833-1121 (Main Switchboard), FAX: +81-44-822-1115 |
| Osaka Office: | 1-7-10 Doshou-machi, Chuo-ku, Osaka City, Osaka JAPAN 541-0045 TEL: +81-6-6205-7001 (Main Switchboard), FAX: +81-6-6205-7031 |
| Nagoya Office: | 4-15-3 Imaiike, Chikusa-ku, Nagoya City, Aichi JAPAN 464-0850 TEL: +81-52-741-7301, Fax: +81-52-741-7303 |
| Nagano Office: | 1920 Yoshikawanomizo, Matsumoto City, Nagano JAPAN 399-0003 TEL: +81-0263-85-1330, FAX: +81-0263-85-1332 |



| 番号 NO. | 記号 SYMBOL | 名称 NAME | 型式 (材質) MODEL (MATERIAL) | 個数 QT. | 摘要 ABSTRACT |
|--------|---------------|---|--------------------------|--------|--------------------------------|
| 1 | P1, M1 | ポンプ PUMP | 40KPD15Z-VU1 | 1 | 1.5kW 端子台付 WITH TERMINAL BLOCK |
| 2 | | VDF | CL-100LW | 1 | |
| 3 | SV1 | アクチュエータ付ボールバルブ BALL VALVE WITH ACTUATOR | 10A | 1 | |
| 4 | SV2 | アクチュエータ付ボールバルブ BALL VALVE WITH ACTUATOR | 32A | 1 | |
| 5 | SV3 | アクチュエータ付ボールバルブ BALL VALVE WITH ACTUATOR | 25A | 1 | |
| 6 | | スラッジポット SLUDGE POT | SCS13 | 1 | |
| 7 | | 制御盤 CONTROL PANEL | | 1 | |
| 8 | LS1, LS2, LS3 | フロートスイッチ FLOAT SWITCH | NKF-3 | 1 | |
| 9 | | エアレギュレータ AIR REGULATOR | SMC:AC20B-02CE 1/4B | 1 | |
| 10 | | アダプタ ADAPTER | SCS13 | 1 | |
| 11 | | スラッジ掻き棒 SCRAPING BAR | A5052/A5056 | 1 | |
| 12 | | スラジタンク SLUDGE TANK | SS/SPCC | 1 | |



| | | | |
|----------------------------|--------------|-----------------|-----------------|
| ENGR. IN CHARGE T. Mori | DRAWING NAME | 外形図 | PAGE 1 |
| CHECKED BY M. Takeishi | | | LAST PAGES 1 |
| DRAWING BY T. Ookubo | DRAWING No. | OUTLINE DRAWING | S0814UE06 |
| DATE '11/28/2008 | | | |
| SCALE 1:10 | | | |

| 番号 | 訂正記事 | 日付 | 担当者 |
|----|------|----|-----|
| △ | | | |

NIKUNI NIKUNI CO., LTD.

| No. | DESCRIPTION | DATE | DRW. |
|-----|-------------|------|------|
| △ | | | |

電源
POWER
AC200/200-220V
50/60Hz
3φ3W

電気信号
ELECTRICAL SIGNAL


7

制御盤
CONTROL PANEL

ダークティ吸込み口
内径38mmホース用ニップル
DIRTY INLET
JOINT FOR HOSE
(BORE DIAMETER 38mm)

圧縮空気入口
COMPRESSED AIR INLET
0.4~1MPa
日東20P
NITTO 20P

9




12

PS 0.3MPaON

ドレン 1/2B
DRAIN 1/2B

3




13

LS1 (満水)
LS2 (上限)
LS3 (下限)

1

M1



8



4

A

6


10

2



濃縮液
CONCENTRATED DIRTY

11



5

クリーン吐出口
内径32mm用ニップル
CLEAN OUTLET
JOINT FOR HOSE
(BORE DIAMETER 32mm)


注1. ○内番号は、装置外形図を参照下さい。
SEE OUTLINE DRAWING TO CHECK THE EQUIPMENT
NAME FOR ITEM No. IN THE BALLOON.

| | | | | | |
|-----------------|-------------|--------------|--------------|-------------|-----------|
| ENGR. IN CHARGE | T. Mori | DRAWING NAME | フロー図 | PAGE | 1 |
| CHECKED BY | M. Takeishi | | | LAST PAGES | 1 |
| DRAWING BY | T. Ookubo | DRAWING No. | FLOW DIAGRAM | DRAWING No. | SO814FS01 |
| DATE | '06/12/2008 | | | | |
| SCALE | None | | | | |



NIKUNI

株式会社 **ニクニ**



| No. | DESCRIPTION | DATE | DRW. |
|-----|-------------|------|------|
| △ | | | |



機器配置図
EQUIPMENT LAYOUT DRAWING



端子台配置図
TERMINAL-BLOCK LAYOUT DRAWING



| | | | |
|--------------|--|-----------|---|
| CAP4 | フレキ用コネ HOSE CLAMP | 1 | 大和電業 DAIWA MS12-16 |
| CAP3 | 膜付グロメット GROMMET | 3 | 協和ゴム工業 KYOWA RUBBER INDUSTRY C-30-SG 22A |
| CAP2 | キャブコン CABLE CLAMP | 2 | オーム電機 OHM ELECTRIC OA-W-1611 |
| CAP1 | キャブコン CABLE CLAMP | 1 | オーム電機 OHM ELECTRIC OA-W-2216 |
| TB3 | 端子台 TERMINAL BLOCK | 20 | 和泉 IDEC IZUMI BN15MW |
| TB2 | 端子台 TERMINAL BLOCK | 4 | 和泉 IDEC IZUMI BN15LW |
| TB1 | 端子台 TERMINAL BLOCK | 4 | 和泉 IDEC IZUMI BN30W |
| WL | 表示灯 INDICATION LIGHT | 1 | 富士電機 FUJI DR22DOL-M9W (AC220V WHITE) |
| GL1 | 表示灯 INDICATION LIGHT | 1 | 富士電機 FUJI DR22DOL-M9G (AC220V GREEN) |
| RL1~4 | 表示灯 INDICATION LIGHT | 4 | 富士電機 FUJI DR22DOL-M9R (AC220V RED) |
| PBS2 | 押しボタンスイッチ PUSH BUTTON SWITCH | 1 | 富士電機 FUJI AR22FOR-01S (BLUE) |
| PBS1 | 押しボタンスイッチ PUSH BUTTON SWITCH | 1 | 富士電機 FUJI AR22V2R-02R (RED) |
| COS1 | セレクトスイッチ SELECTOR SWITCH | 1 | 富士電機 FUJI AR22PR-210B |
| | ソケット SOCKET | 1 | 松下制御 MATSUSHITA HJ4-SFD |
| X1 | ミニパワーリレー CONTROL RELAY | 1 | 松下制御 MATSUSHITA HJ4-L-AC200V-6 |
| | ソケット SOCKET | 1 | 松下制御 MATSUSHITA ATC180041 11ピン |
| T1 | タイマー TIMER | 1 | 松下制御 MATSUSHITA PM4HA-H-AC240V |
| PLC | プログラマブルコントローラ PROGRAMMABLE CONTROLLER | 1 | 松下制御 MATSUSHITA AFPX-C30R |
| SK1 | サージキラー SURGE KILLER | 1 | 富士電機 FUJI SZ-ZM1 |
| MC1 | 電磁開閉器 ELECTROMAGNETIC SWITCH | 1 | 富士電機 FUJI SW-03/3H AC200V 6A AC200V 1a |
| THR1 | サーキットプロテクタ CIRCUIT PROTECTOR | 1 | 松下制御 MATSUSHITA BACS101105 1A |
| ELB | 漏電遮断器 EARTH LEAKAGE BREAKER | 1 | 三菱電機 MITSUBISHI NV30-FA 3P 20AT 30mA |
| 記号 SYMBOL | 名称 NAME | 個数 QT. | 備考 MODEL |

盤仕様
CONTROL PANEL SPECIFICATION
形状: CH制御盤ボックス (IP4X)
TYPE: CH CONTROL BOX (IP4X)
CH16-34 (日東工業製)
CH16-34 (NITTO)

| | | | |
|----------------------------|--------------|------------------|-----------------|
| ENGR. IN CHARGE T. Mori | DRAWING NAME | 制御盤外形図 | PAGE 1 |
| CHECKED BY M. Takeishi | | | LAST PAGES 2 |
| DRAWING BY T. Ookubo | | DRAWING No. | S0814CP07 |
| DATE '11/28/2008 | SCALE 1:5 | NIKUNI CO., LTD. | |

| No. | DESCRIPTION | DATE | DRW. |
|-----|-------------|------|------|
| △ | | | |


C-Jaguar操作盤
C-Jaguar Operating Panel



PBS2




COS1



PBS1

| | | | |
|-------------------------|--------------|-------------------------------|--------------|
| ENGR. IN CHARGE T. Mori | DRAWING NAME | 制御盤外形図 | PAGE 2 |
| CHECKED BY M. Takeishi | | CONTROL PANEL OUTLINE DRAWING | LAST PAGES 2 |
| DRAWING BY T. Ookubo | | | |
| DATE '11/28/2008 | | | |
| SCALE Free | DRAWING No. | SO814CPO7 | △ 0 |

| No. | DESCRIPTION | DATE | DRW. |
|-----|-------------|------|------|
| △ | | | |




| | | | |
|----------------------------|--------------|-----------------------------------|-----------------|
| ENGR. IN CHARGE T. Mori | DRAWING NAME | 電気回路図 ELECTRIC CIRCUIT DIAGRAM | PAGE 1 |
| CHECKED BY M. Takeishi | | | LAST PAGES 4 |
| DRAWING BY T. Ookubo | DRAWING No. | S0814CPO4 | △ 0 |
| DATE '10/09/2008 | | | |
| SCALE None | | | |

NIKUNI

NIKUNI CO., LTD.

| No. | DESCRIPTION | DATE | DRW. |
|-----|-------------|------|------|
| △ | | | |



| | |
|-----------------|-------------|
| ENGR. IN CHARGE | T. Mori |
| CHECKED BY | M. Takeishi |
| DRAWING BY | T. Ookubo |
| DATE | '10/09/2008 |
| SCALE | None |

DRAWING NAME
DRAWING No.

電気回路図
ELECTRIC CIRCUIT DIAGRAM


S0814CPO4

| | |
|------------|--------|
| PAGE | 2 |
| LAST PAGES | 4 |
| | △ 0 |

NIKUNI

NIKUNI CO., LTD.

| No. | DESCRIPTION | DATE | DRW. |
|-----|-------------|------|------|
| △ | | | |



SV1, 2, 3~中継端子箱:フレキ配線

BETWEEN SV1, 2, 3 TO RELAY TERMINAL BOX :FLEXIBLE HOSE

SV1, 2, 3外配線:0.75mm² VCTFキャプタイヤ4芯


SV1, 2, 3 ELECTRIC WIRE:0.75mm² PVC SHEATHED CAB TYRE CORD

| | | | |
|----------------------------|--------------|-----------------------------------|-----------------|
| ENGR. IN CHARGE T. Mori | DRAWING NAME | 電気回路図 ELECTRIC CIRCUIT DIAGRAM | PAGE 3 |
| CHECKED BY M. Takeishi | | | LAST PAGES 4 |
| DRAWING BY T. Ookubo | DRAWING No. | S0814CPO4 | △ 0 |
| DATE '10/09/2008 | | | |
| SCALE None | | | |


NIKUNI

NI KUNI CO., LTD.

| No. | DESCRIPTION | DATE | DRW. |
|-----|-------------|------|------|
| △ | | | |




異常信号出力 (正常時:閉)
 FILTRATION UNIT ALM
 (NORMALLY CLOSED)



| | | | | |
|-------------------------|--------------|-----------------------|--------------------------|--------------|
| ENGR. IN CHARGE T. Mori | DRAWING NAME | 電気回路図 | PAGE 4 | |
| CHECKED BY M. Takeishi | | | ELECTRIC CIRCUIT DIAGRAM | LAST PAGES 4 |
| DRAWING BY T. Ookubo | | DRAWING No. S0814CPO4 | △ 0 | |
| DATE '10/09/2008 | | | | |
| SCALE None | | | | |

Nikuni

NI KUNI CO., LTD.



Supplementary Information

※1. Basic operations in one cycle are as follows:

[clean fluid supply + sludge precipitation → clean fluid supply
→ clean fluid supply + supernatant discharge → concentrate discharge SV2 open/close

※2. If the fluid level has not reached the upper limit as starting time, open SV2 and supply fluid to the tank

※3. If the supernatant discharge time (SV1 open time) of 3 min. or longer has elapsed, a RL3 fluid discharge error occurs.

※4. COS1 or IN1 stops after completion of one cycle.

※ Refer to the Timing Diagram together with the Flow Chart.

| | | | |
|--|-------------|------------------|----------------|
| PRODUCT NAME: Cyclone catcher with sludge tank | | TYPE: C-Jaguar | |
| ENGR. IN CHARGE | T. Mori | DRAWING NAME | Timing Diagram |
| CHECKED BY | M. Takeishi | | タイミングチャート |
| DRAWING BY | T. Ookubo | DRAWING No. | S0814F002 |
| DATE | 01/27/2008 | | |
| SCALE | Free | | |
| NIKUNI | | NIKUNI CO., LTD. | |